

Silver Series MID & LRG 360 Turntable Hanging Kit Set up Guide



Along with the purchase of your Hanging Kit, you would have received:

- A. Hanging Kit Mount (circle piece): This will mount to the stem on the turntable using 3 screws
- B. Screws: Used to mount Hanging Kit Mount to turntable and for connecting Stems to the Mount
- C. 2X Hanging Kit Stems (1 for Plate/Hook Mount, 1 for Watch Stand Mount)
- D. Two Hanging Kit Plates (not pictured):
 - a. **Small Plate Mount:** 6" x 3" – this part is designed for photographing hanging necklaces and similar smaller type objects in 360. Also can be used with fishing line or wire
 - b. **Large Plate Mount:** 11.75 x 4" – this part is ideal for use with wire or fishing line and optimal for shooting larger size objects such as footwear, handbags and other larger objects
- E. Hook Mount: Designed for shooting hanging earrings and similar type objects in 360

- F. Watch Mount: Specifically designed for 360 Watch Photography
- G. Rubber Feet: These will be used under the turntable to suspend it when placed upside down
- H. Suspension Feet Adhesive: Double sided adhesive that can be used to securely connect feet to turntable surface (optional)

Getting Started with 360 Hanging Kit

Users will first want to find a surface in which they can suspend their turntable upside down. We find a piece of wood with a hole drilled out in the middle works best however other options are available too. In the image below, we used a 2 x 4' sheet of plywood and drilled a 3" circle hole in the middle using a hole saw drill bit. We then suspended this platform using 2 31" tall saw horses.



Figure 1: Turntable Suspension

Next, the turntable platform will need to be removed (remove the 3 screws used to mount this top to the turntable stem) then remove the roller bearings.



Figure 2: Removing screws & deciding turntable stem

It is in this next step users will decide which hanging kit stem will be required.

- If using the Watch Stand Mount, use the Stem with the white connector mount on one end (part A, Figure 2 - see above)
- If using either of the plates or the Hook, then use the connector mount with metal screw mount on both ends (part B, Figure 2 - see above).

Connect the stem to the hanging kit mount (circle piece) using the provided screw (see Figure 3 below):



Figure 3: Connecting Stem to Turntable Mount

Next, use the 3 screws that were used to mount the turntable platform to connect the Hanging Kit Mount to the center stem (see Figure 4):



Figure 4: Connecting Mount to Turntable Stem

After the mount has been attached, its time to flip the turntable upside down. Users can either:

1. Adhere the rubber feet to the turntable (using the provided Suspension Feet Adhesive (red dots) – this is optional. See Figure 5
2. Place the turntable upside down and place the feet under it. See Figure 6 for suggested feet placement



Figure 5: Place adhesive on Rubber Feet



Figure 6: Showing suggested rubber feet placement

Flip Turntable upside down and place stem through hole (see Figure 7)



Figure 7: Flip Turntable upside down and place stem through hole

Last, user will attach the required mount to the Stem using a screw (see Figure 8 and 9):



Figure 8: Connect plate



Figure 8: Screw in plate

Questions? All purchases include free support, please go to: <https://www.iconasys.com/technical-support/> to see support contact options





